

**Thank you for your interest in our schematics.** The schematic is available on the next page.


If you want to download additional parts of a schematic, or additional schematics, these must be requested individually.

To provide you with this information, more than 6000 members work regularly on the content of Radiomuseum.org.

As a member, you can access schematics, large images without watermarks and collector's prices. You will also surf at Radiomuseum.org without advertising. To do so, you may support Radiomuseum.org with a one-time membership fee of 20 € or 30 CHF or 25 US \$. We would be delighted if you joined as a member:


[https://www.radiomuseum.org/dsp\\_anmelden\\_start.cfm](https://www.radiomuseum.org/dsp_anmelden_start.cfm)

#### These books might be of interest of you:




#### **Hello, Everybody! The Dawn of American Radio**

Long before the Internet, another young technology was transforming the way we connect with the world. At the dawn of the twentieth century, radio grew from an obscure hobby into a mass medium with the power to reach millions of people.



#### **The Rise of Radio, from Marconi through the Golden Age**

As the dominant form of electronic mass communication in the United States from the 1930s into the 1950s, radio helped to forge a modern continental nation. It fused myriad subcultures heavily rural, ethnic, and immigrant into a national identity, unifying the nation in the face of the Depression and war.




#### **The Paraset Radio: The Story of a WWII Spy-Radio and How to Build a Working Replica**

This book describes the gripping story behind the Paraset – a unique spy-radio, dropped behind enemy lines in the dark days of WWII. This radio being both light weight and state of the art for the time was concealed in a suitcase, making ideal for use by the spies of SOE.

Click [here](#) for further information.


nepenuck@gmail.com



Bereich	Schwingungsspannung	Röhrenvoltmeter an
KW	80 - 250mV	gemessen mit Messwiderstand an VTVM of
49m	50 - 150mV	
MW	70 - 150mV	
LW	70 - 150mV	
U	90 - 110mV	5

H1130

Gleichspannungen Tol. ±15%, mit Röhrenvoltmeter  $R_i \geq 10 M \Omega$  gegen  $\perp$  gemessen (ohne Signal)  
 DC voltages: tol. ±15%, measured with VTVM  $R_i \geq 10 M \Omega$  against  $\perp$  (without signal)  
 Werte ohne Klammern in Schalterstellung AM  
 Werte eingeklammert in Schalterstellung FM  
 Values without brackets for position AM  
 Values in brackets for position FM  
 Die Schwingungsspannungen sind vom Mischtransistor AF 201 (V902) bzw. AF 201 C (V702) abhängig.  
 The oscillator voltages depend on the transistor AF 201 (V902) resp. AF 201 C (V702)  
 Für Werte ohne Bezeichnung pF oder  $\Omega$  einsetzen.  
 Read pF or  $\Omega$  unless otherwise noted.



Gezeichnete Schalterstellung Änderungen vorbehalten!